



## Ignition system, servicing


### General notes:

- ◆ *Only components specifically related to the ignition system are contained in this Repair Group. For the other Fuel injection components ⇒ [page 24-1](#) .*
- ◆ *Always switch OFF the ignition when disconnecting and connecting the battery, otherwise the Engine Control Module (ECM) could be damaged.*
- ◆ *The Engine Control Module is equipped with an On Board Diagnostic system.*
- ◆ *Components marked with an \* are checked via On Board Diagnostic. ⇒ [Page 01-11](#) , Check DTC memory*
- ◆ *11.5 Volts minimum is required for trouble-free operation of the electrical components.*
- ◆ *While performing certain checks it is possible that the ECM will recognize and store a Diagnostic Trouble Code (DTC). Therefore after*

*completing all checks and repairs, Check and erase the DTC memory as necessary. ⇒ [Page 01-11](#), Check DTC memory*

Safety precautions ⇒ [Page 28-5](#)

Test data, spark plugs ⇒ [Page 28-6](#)



## Ignition system components, removing and installing

### 1 - 5-pin harness connector

- ◆ Black

### 2 - Ignition Coil Power Output stage N122

- ◆ Checking ⇒ [Page 28-9](#)
- ◆ Coat lower part with heat conductive paste G 052 170 A2

### 3 - 6 Nm (53 in. lb)

### 4 - 4-pin harness connector

- ◆ Black

### 5 - 10 Nm (7 ft lb)

- ◆ Only loosen or tighten with ignition switched off

### 6 - Ground wire


- ◆ Only loosen or tighten with ignition switched off

### 7 - 3-pin harness connector

- ◆ Black

### 8 - Connector Lock

N28-0056



### 9 - Ignition coils N, N128, N158 and N163

- ◆ Spark plug connector can be pulled off
- ◆ Checking ⇒ [Page 28-9](#)

### 10 - Oil seal

- ◆ Replace if damaged

### 11 - Spark plug

- ◆ 30 Nm (22 ft lb)
- ◆ Remove and install using 3122B
- ◆ Type and electrode gap ⇒ [Page 28-6](#) , test data, spark plugs

### 12 - 3-pin harness connector

- ◆ Gold plated terminals
- ◆ Green for knock sensor 1 G61
- ◆ Blue for knock sensor 2 G66


### 13 - 20 Nm (15 ft lb)

- ◆ Tightening torque influences knock sensor function

### 14 - Knock sensor 1 G61\*

- ◆ Green

- ◆ Gold-plated sensor and connector terminals
- ◆ Checking ⇒ [Page 28-13](#)



### 15 - Knock sensor 2 G66\*

- ◆ Blue
- ◆ Gold-plated sensor and connector terminals
- ◆ Checking ⇒ [Page 28-13](#)

### 16 - 3-pin harness connector

- ◆ Black
- ◆ for Camshaft Position sensor G40

### 17 - 10 Nm (7 ft lb)

### 18 - Camshaft Position sensor G40

- ◆ Checking ⇒ [Page 28-7](#)

### 19 - 25 Nm (18 ft lb)

### 20 - Conical washer

### 21 - Hood

- ◆ for Camshaft Position sensor G40
- ◆ When installing, note installation arrangement


### 22 - Heat sink



## Safety precautions

To prevent injuries to persons and/or damage to the fuel injection and ignition system, the following must be noted:

- ◆ Do not touch or disconnect ignition wiring when the engine is running or being turned at starter speed.
- ◆ The ignition must be switched off before connecting or disconnecting injection or ignition system wiring or tester cables.
- ◆ If the engine is to be turned at starter speed, without starting:



A

- Disconnect 5 pin connector -1- off output stage for ignition coils -2-.

Observe following if test and measuring instruments are required during a test drive:

- ◆ Test and measuring instruments must be secured to rear seat and operated by a 2nd person from this location.

If test and measuring instruments are operated from front passenger's seat and the vehicle is involved in an accident, there is a possibility that the person sitting in this seat may receive serious injuries when the airbag is triggered.



## Test data, spark plugs

<b>Engine code</b>	<b>AEB</b>
<b>Firing order</b>	1-3-4-2
<b>Spark plugs</b>	
VW/Audi	101 000 051 AA
Manufacturer's number	F 7 LTCR
Electrode gap	0.9 to 1.1 mm (0.35 to 0.43 in.)
Tightening torque	30 Nm 22 ft lb)





## Camshaft position sensor, checking

### Special tools, testers, measuring instruments and auxiliary items required


- ◆ VAG 1598/22 Test Box
- ◆ Fluke 83 multimeter
- ◆ VW 1594 Adaptor kit
- ◆ Wiring diagram

### Test conditions


- Battery voltage must be 11.5 Volts minimum

### Test sequence


- Disconnect 3-pin harness connector -1- off Camshaft Position sensor -2-.
- Switch multimeter to Voltage measurement range
- Connect multimeter between outer terminals of connector using jumper wires from VW 1594
- Switch ON ignition.



- Specification: min. 4.5 Volts
- Switch OFF ignition.



- A**
- Connect test box VAG 1598/22 to Engine Control Module harness connector.



- A**
- Check wiring between Test Box and harness connector using wiring diagram  
Terminal 1 + socket 11 Terminal 2 + socket 76 Terminal 3 + socket 67 Wire  
resistance: Max. 1.5  $\Omega$
  - Check wires for shorting to one another.
    - Specification:  $\infty \Omega$

If wiring OK and voltage present between terminals 1 + 3

- Replace Camshaft Position sensor G40.

If wiring OK and no voltage present between terminals 1 + 3

- Replace Engine Control Module  $\Rightarrow$  [Page 24-128](#) .



## Ignition coil power output stage, checking

### Special tools, testers, measuring instruments and auxiliary items required

- ◆ VAG 1598/22 Test Box
- ◆ Fluke 83 multimeter
- ◆ VW 1594 Adaptor kit
- ◆ VAG 1527 B Voltage tester
- ◆ Wiring diagram

### Checking requirements


- Battery voltage must be 11.5 Volts minimum
- Camshaft Position sensor must be OK, checking ⇒ [Page 28-7](#) .
- Engine Speed sensor must be OK, checking ⇒ [Page 24-69](#) .

- Fuse 32 OK.
- Ground connections ⇒ [Page 28-2](#) (item 6 must be OK).



### Activation, checking

- Disconnect harness connector from all fuel injectors.



A


- Disconnect 5-pin harness connector -1- from Power Output Stage for ignition coils -2-.
- Connect VAG 1527 B Voltage tester to terminals 1 + 3 using jumper wires from VW 1594 adaptor kit.
- Operate starter and check ignition signal from ECM.
  - LED must flicker
- Repeat check between terminals 2, 4, 5 and 3 (Ground).

If LED does not flicker:

- Check wiring ⇒ [Page 28-12](#)

### Power Output stage, checking

- Re-connect 5-pin harness connector on Power Output stage.



A

- Disconnect 4-pin harness connector -1- from Ignition coil Power Output Stage -2-
- Connect VAG 1527 B Voltage tester to terminal 1 of Ignition coil Power Output Stage -2- and battery positive (+) using jumper wires from VW 1594 adaptor kit.

- Operate starter.
- LED must flicker
- Repeat check between terminals 2, 3 and 4.



If LED does not flicker

- Replace Power Output stage ⇒ [Page 28-2](#) (item 2)



### Checking ignition coils

- Switch ON ignition.
- A** - Connect diode test lamp VAG 1527 with aux. cables from VAG 1594 to terminal 1 of 4 pin connector and to battery negative (-)
  - LED must light up
- Repeat check between terminals 2, 3 and 4.

If LED does not flicker on one terminal:

- A** - Check for open circuit between 4-pin harness connector and (relevant ignition coil) 3-pin harness connector (terminal 1) using wiring diagram.
  - Wire resistance: Max. 1.5  $\Omega$

If wiring OK






- Replace ignition coil.




### Wiring, checking

- Switch OFF ignition.



A

- Disconnect 5-pin harness connector -1- from Ignition coil Power Output stage -2-



A

- Connect VAG 1598/22 Test Box to Engine Control Module harness connector.

- Check wiring between Test Box and 5-pin harness connector for open circuit using wiring diagram. Terminal 1 + socket 70 Terminal 2 + socket 78 Terminal 3 + socket 2 Terminal 4 + socket 77 Terminal 5 + socket 71 Wire resistance: Max. 1.5  $\Omega$



---

## Knock sensor, checking

### Notes:

- ◆ *Knock sensor torque must be maintained at 20 Nm (15 ft lb) to ensure the knock sensors function correctly.*
- ◆ *Only gold-plated terminals may be used when servicing the knock sensor connector terminals.*

### Special tools, testers, measuring instruments and auxiliary items required

- ◆ VAG 1598/22 Test Box
- ◆ Fluke 83 multimeter
- ◆ VW 1594 Adaptor kit
- ◆ VAG 1527 B Voltage tester
- ◆ Wiring diagram

### Test conditions


- On Board Diagnostic must have recognized a DTC for one or both knock sensors.

### **Checking function**

- Functional check of knock control and knock sensors ⇒ [Page 01-60](#) "Read measuring value block" display groups 14 to 16 and 24




## Checking resistances and wiring



A

- Disconnect 3-pin harness connector (green) to knock sensor 1 G61 -1- and / or 3-pin connector (blue) to knock sensor 2 (G66) -2-.
- Measure resistance between the terminals 1+2, 1+3 and 2+3 at connections to knock sensors.
  - Specification  $\infty \Omega$



A

- Connect test box VAG 1598/22 to Engine Control Module wiring harness.
- Check wiring for open circuit between Test Box and 3-pin harness connector using wiring diagram.

G61:                      G66:

Terminal 1 + socket 68    60

Terminal 2 + socket 67    67

Terminal 3 + socket 2      2

Wire resistance: Max. 1.5  $\Omega$

- Check wiring at socket 67 for short to sockets 60 and 68.
  - Specification:  $\infty \Omega$



If wiring OK

- Loosen knock sensor and tighten again
- 20 Nm (15 ft lb) CRITICAL TORQUE
- Perform road test.

During road test following operating conditions must be fulfilled:

- ◆ Engine Coolant temperature must exceed 80 ° C .
  - ◆ After Engine Coolant Temperature is reached, the following operating conditions must be attained several times: Closed throttle (idle) Partial throttle Wide Open Throttle Overrun
  - ◆ At Wide Open Throttle, engine speed must exceed 3500 rpm.
- Check ECM Diagnostic Trouble Code memory.

If knock sensor DTC still stored

- Replace knock sensor(s)



## Misfiring detection, checking

### Special tools, testers, measuring instruments and auxiliary items required

- ◆ VAG 1551/1552 Scan Tool with VAG 1551/3 cable

### Test sequence

- Connect VAG 1551/1552 Scan Tool ⇒ [Page 01-8](#).
- Start engine and let idle
- Press 0 and 1 buttons to select Address word 01: "Engine electronics"

Rapid data transfer      HELP  
Select function XX



Display will appear as shown:

- Press 0 and 8 buttons to select Function 08: "Read measuring value blocks"
- Press Q button to enter input

Read measured value block      HELP  
Input display group number XXX



Display will appear as shown:

- Press 0, 1 and 4 buttons to select "Display group 014"



Read measured value block 14 →  
1      2      3      4

- Press Q button to enter input

↩ Display will appear as shown (1 to 4 = Display zones)

- Check specification for misfire detection (display zones 3 to 4):



	Display zones			
	1	2	3	4
<b>Display group 14: Misfiring recognition</b>				
Display	xxx rpm	xx.xx ms	xxx	Active Blocked
Indicated	Engine speed (in 40 steps)	Engine load	Misfiring adversely affecting exhaust (total)	Misfiring recognition status
Working range	0 to 6800 rpm	0.00 to 8.50 ms	0 to 500	---
Specific.	820 to 900 rpm	0.5 to 1.5 ms	0 to 20	Activated

**Note:**

*If DTC memory has been erased or the Engine Control Module was disconnected from its Voltage supply, the Readiness Code must be created again ⇒ [Page 01-46](#) .*

If specification is attained:

- Press → button.
- Press 0 and 6 buttons to select Function 06:  
"End data transfer"
- Press Q button to enter input

If specifications are not obtained:

- Press C button.
- Press 0, 1 and 5 buttons to select "Display group 015"
- Press Q button to enter input

Read measured value block 15 →



Display will appear as shown: (1 to 4 = Display zones)

1      2      3      4

- Check specification for misfire detection (display zones 1 to 4):



	Display zones			
	1	2	3	4
<b>Display group 15: Misfire recognition</b>				
Display	xxx	xxx	xxx	Active Blocked
Indicated	Misfiring adversely affecting No. 1 Cyl.	Misfiring adversely affecting No. 2 Cyl.	Misfiring adversely affecting No. 3 Cyl.	Misfire recognition status
Working range	0 to 500	0 to 500	0 to 500	---
Specification	0 to 5	0 to 5	0 to 5	Activated
	If specification not obtained ⇒ <a href="#">Page 28-22</a> , evaluating display groups 15 and 16			



If specification attained:

- Press C button.
- Press 0, 1 and 6 buttons to select "Display group 016"
- Press Q button to enter input

Read measured value block 16 →

1      2      3      4



Display will appear as shown: (1 to 4 = Display zones)

- Check specification for misfire recognition, display zones 1 and 4



	Display zones			
	1	2	3	4
<b>Display group 16: Misfiring recognition</b>				
Display	xxx	---	---	Active Blocked
Indicated	Misfiring adversely affecting No. 4 Cyl.	---	---	Misfire detection status
Working range	0 to 500	---	---	---
Specification	0 to 5	---	---	Active
If specification not obtained ⇒ <a href="#">Page 28-22</a> , evaluating display groups 15 and 16				



### Evaluating display groups 15 and 16

Display groups: 15 and 16	Possible cause of malfunction	Malfunction elimination
Display zone: 1 to 4		
More than 5	<ul style="list-style-type: none"> <li>◆ Ignition coil faulty</li> <li>◆ Spark plug connector faulty</li> <li>◆ Spark plug faulty</li> <li>◆ Ignition coil output stage faulty</li> </ul>	- Check ignition coil Power Output stage ⇒ <a href="#">Page 28-9</a>
	<ul style="list-style-type: none"> <li>◆ Injector faulty</li> <li>◆ Fuel shortage</li> </ul>	<ul style="list-style-type: none"> <li>- Check fuel injectors ⇒ <a href="#">Page 24-75</a></li> <li>- Check quantity of fuel in tank</li> </ul>