

Component Locations

[G66 – Knock Sensor \(KS\) 2 \(2.8 ltr. engine\)](#)

[G66 – Knock Sensor \(KS\) 2 \(1.8 ltr. engine\)](#)