

A/C Component Locations Overview – Engine Compartment

- 1 Accumulator
- 4 Low pressure service valve
- 5 High pressure service valve
- 6 Dust and pollen filter Vehicles from 10.00,
- 7 Evaporator In heating and A/C unit
- 8 Engine Coolant (EC) Switch-Off Valve (heater) -N279- 8-cylinder engine only
- 10 Pressure relief valve
- 11 Coolant Fan Control (FC) Control Module -J293-
- **12** Compressor A/C Clutch -N25- on 4 & 6 cylinder engines.Externally regulated compressor without A/C clutch -N25- on 8-cylinder engine
- 13 A/C Clutch -N25- Not for 8-cylinder engine
- 14 Condenser
- 15 Outside Air Temperature Sensor -G17-
- 16 A/C Pressure Switch -F129- or High Pressure Sensor -G65- Note: Application is engine dependent.
- q A/C Pressure Switch -F129-, from 10.00