

Oil pressure switch (1.8 ltr. engine)

• on driver's side of cylinder block, center, in oil filter housing