



**G28 Engine Speed (RPM) sensor (1.8 ltr. engine)**

- on driver's side of cylinder block, near transmission flange