



G46 Left rear ABS wheel speed sensor

- in driver's side rear wheel bearing housing
  passenger side –G44– shown