



G47 Left front ABS wheel speed sensor

• in driver's side front wheel bearing housing