

Fresh air intake duct temperature sensor

• in fresh air plenum, under dust and pollen filter, in duct