



J104 **ABS control module (w/out EDL)**

- in engine compartment, driver's side, forward of upper suspension mount